


Tondeuse tractée thermique




Manuel Pièces de Rechange


Ensemble Tondeuse Tractée LBP56




Rep/N°	Réf Sanli	Gencod	Libellé
1	1940	3700554619402	Bouchon enjoliveur
2+3	1941	3700554619419	Clips de retenue + rondelle
4	1942	3700554619426	Roulement de roue
5	1943	3700554619433	Roue avant
6+7+8	1944	3700554619440	Kit fixation essieu avant
9	1945	3700554619457	Essieu avant
10	1946	3700554619464	Roue arrière
11	1947	3700554619471	Protège poussière
6+12	1948	3700554619488	Kit fixation essieu arrière
13	1949	3700554619495	Essieu arrière
54+55+56	1950	3700554619501	Kit bavette arrière de sécurité



Rep/N°	Réf Sanli	Gencod	Libellé
15	1951	3700554619518	Secteur de hauteur de coupe
14+16+21	1952	3700554619525	Kit visserie
18+19	1953	3700554619532	Fixation mollette guidon inférieur
17+20	1954	3700554619549	Support guidon droit
22+23+24+25	1955	3700554619556	Kit fixation volet de bac
26	1956	3700554619563	Circlip de retenue pignon
27+28	1957	3700554619570	Pignon et goupille de traction droit
29+30	1958	3700554619587	Roulement + bague
31	1959	3700554619594	Levier de hauteur de coupe
32+37+38	1960	3700554619600	Kit circlip+goupille+rondelle
33	2153	3700554621535	Boîtier de traction
39+28	1961	3700554619617	Pignon et goupille de traction gauche
40	1962	3700554619624	Volet de bac
42	2050	3700554620507	Plaque renfort



Rep/N°	Réf Sanli	Gencod	Libellé
S1			Moteur B&S DOV750
43	1963	3700554619631	Support guidon gauche
44	1964	3700554619648	Barre de hauteur centralisée
45+46	1965	3700554619655	Ressort de hauteur centralisée
47	1966	3700554619662	Carter de coupe
49	1967	3700554619679	Défecteur
51	1968	3700554619686	Protège courroie
S2+S3	2046	3700554620460	Vis de lame
S6+S8	2047	3700554620477	Support de lame
S7	2048	3700554620484	Clavette demi lune
S5	2049	3700554620491	Fusibles de lame
S4	1969	3700554619693	Lame 56cm
S9 + S10	1970	3700554619709	Vis fixation moteur
S11	1971	3700554619716	Protection de courroie
S12	1972	3700554619723	Courroie
S13+S14+S15	1973	3700554619730	Poulie équipée
53	1974	3700554619747	Tôle carénage








Rep/N°	Réf Sanli	Gencod	Libellé
58	1975	3700554619754	Câble présence opérateur
59	1976	3700554619761	Guidon inférieur
60	1977	3700554619778	Guidon supérieur
61	1978	3700554619785	Câble régime moteur
63	1979	3700554619792	Poignée de traction
66	1980	3700554619808	Poignée présence opérateur
68+19	1981	3700554619815	Fixation mollette guidon supérieur
69	1982	3700554619822	Câble traction
70	1983	3700554619839	Bac à herbe










MOTEUR BRIGGS & STRATTON DOV750


Modèle 100800
Type 0015 à 2114

100800






















100800



1036 EMISSIONS LABEL

1058 OPERATOR'S MANUAL



100800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	795396	Cylinder Assembly	24	222698S	Key-Flywheel	81	691740	Lock-Muffler Screw
2	796961	Kit-Bushing/Seal	25	793519	Piston Assembly (Standard)	104	698536	Pin-Float Hinge
3	299819S	Seal-Oil (Magnet Side)			----- Note -----	105	698537	Valve-Float Needle
4	793509	Sump-Engine			793518 Piston Assembly (.020" Oversize)	117A	793694	Jet-Main (Standard)
5	793502	Head-Cylinder				118A	793695	Jet-Main (High Altitude)
7	793455	Gasket-Cylinder Head	26	793435	Ring Set (Standard)	121	793622	Kit-Carburetor Overhaul
9	793439	Gasket-Breather			----- Note -----	122	793456	Spacer-Carburetor
11	793447	Tube-Breather			793517 Ring Set (.020" Oversize)	125A	793493	Carburetor (Ready Start System)
12	793445	Gasket-Crankcase (.015" Thick) (Standard)	27	691588	Lock-Piston Pin	133	698539	Float-Carburetor
13	793451	Screw (Cylinder Head) (M8x71.0mm Long)	28	298909	Pin-Piston (Standard)	137	698538	Gasket-Float Bowl
15	691680	Plug-Oil Drain	29	793510	Rod-Connecting	163	691894	Gasket-Air Cleaner
16	793426	Crankshaft Used on Type No(s). 0025, 0062, 0117, 0118, 0124, 0125, 0220, 2025.	32	691664	Screw (Connecting Rod) (1 3/32" Long)	187	791766	Line-Fuel (Cut to Required Length)
		----- Note -----	32A	695759	Screw (Connecting Rod) (1 1/2" Long)	202	793433	Link-Mechanical Governor
		793615 Crankshaft Used on Type No(s). 0015, 0109, 0115, 0116, 0123, 0126, 0136, 2015, 2109, 2112.	33	793505	Valve-Exhaust	209	793427	Spring-Governor Used on Type No(s). 0015, 0025, 0062, 0115, 0117, 0118, 0121, 0126, 0220, 2015, 2025.
			34	793504	Valve-Intake			----- Note -----
			35	793506	Spring-Valve (Intake)			793604 Spring-Governor Used on Type No(s). 0109, 0110, 0111, 0123, 0124, 0136, 0137, 2109, 2110, 2111, 2112.
			36	793506	Spring-Valve (Exhaust)			793430 Spring-Governor Used on Type No(s). 0116, 0120, 0125, 0134.
								799301 Spring-Governor Used on Type No(s). 2114.
			37	793473	Guard-Flywheel (Rewind Starter) Used on Type No(s). 0015, 0025, 0109, 0110, 0111, 0115, 0116, 0117, 0118, 0120, 0121, 0123, 0124, 0125, 0126, 0134, 0136, 0137, 2015, 2025, 2109, 2110, 2111.	216	793494	Link-Choke
20	399781S	Seal-Oil (PTO Side)	37A	794106	Guard-Flywheel (Electric Starter) Used on Type No(s). 0062, 0220, 2112, 2114.	217	797864	Spring-Choke Return
22	793450	Screw (Crankcase Cover/Sump) (40.5mm)	40	793503	Retainer-Valve	219	793512	Gear-Governor
23	793619	Flywheel Used on Type No(s). 0015, 0025, 0115, 0117, 0118, 0120, 0121, 0123, 0124, 0125, 0126, 0134, 0136, 0137, 0220, 2015, 2025.	51	692555	Gasket-Intake	222	793487	Bracket-Control
		----- Note -----	58	697316	Rope-Starter (88 5/8" Long)	227	793516	Lever-Governor Control
		793682 Flywheel Used on Type No(s). 0062, 0109, 0110, 0111, 0116, 2109, 2110, 2111, 2112, 2114.	60	281434S	Grip-Starter Rope			
			75	691736	Washer (Flywheel)			
			78	793480	Screw (Flywheel Guard) (M8x14.1mm Long)			



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
236	691826	Link-Lockout Used on Type No(s). 0015, 0025. ----- Note ----- 796161 Link-Lockout Used on Type No(s). 0120, 0125, 0220. 796161 Link-Lockout (Used After Code Date 08061500). Used on Type No(s). 0062, 2015, 2025. 691826 Link-Lockout (Used Before Code Date 08061600). Used on Type No(s). 0062, 2015, 2025.	309	796386	Motor-Starter	445	792038	Filter-Air Cleaner Cartridge
			332	690662	Nut (Flywheel) (SAE) (.625-18 I.D.)	474	794103	Alternator
			332A	792723	Nut (Flywheel) (Metric) (M16x1.5mm I.D.)	505	793515	Nut (Governor Control Lever)
			333	793449	Armature-Magneto	513	795100	Clutch-Drive
			334	793454	Screw (Magneto Armature)	523	793475	Dipstick
			337	692051	Plug-Spark Used on Type No(s). 0015, 0121, 0137, 2015. ----- Note ----- 692720 Plug-Spark Used on Type No(s). 0025, 0062, 0109, 0110, 0111, 0115, 0116, 0117, 0118, 0120, 0123, 0124, 0125, 0126, 0134, 0136, 0220, 2025, 2109, 2110, 2111, 2112, 2114.	524	793476	Seal-Dipstick Tube
						525	793477	Tube-Dipstick
						535	793676	Filter-Air Cleaner Foam
238	793535	Cap-Valve				562	793514	Bolt (Governor Control Lever)
265	690798	Clamp-Casing				578	398153	Wire Assembly Used on Type No(s). 0015, 0025, 0062, 0120, 0125, 0220, 2015, 2025.
267	691044	Screw (Casing Clamp)				578A	794104	Wire Assembly Used on Type No(s). 0062, 0220.
276	793627	Washer-Sealing				578C	796996	Wire Assembly Used on Type No(s). 2112.
291	793498	Thermostat				592	793481	Nut (Rewind Starter)
300A	793496	Muffler Used on Type No(s). 0015, 0025, 0111, 0115, 0116, 0117, 0118, 0120, 0121, 0124, 0125, 0134, 0136, 0137, 2015, 2025, 2111, 2114.	356	692390	Wire-Stop Used on Type No(s). 0111, 0115, 0116, 0117, 0118, 0121, 0123, 0124, 0126, 0136, 0137, 2111, 2114.	601	791850	Hose-Clamp (Green)
			356C	690808	Wire-Stop Used on Type No(s). 0109, 0110, 2109, 2110, 2112.	608	793470	Starter-Rewind
300B	793679	Muffler Used on Type No(s). 0062, 0109, 0110, 0123, 0126, 0220, 2109, 2110, 2112.	358	793623	Gasket Set-Engine	613A	793495	Screw (Muffler)
			363	19069	Puller-Flywheel	613B	793680	Screw (Muffler)
304	793486	Housing-Blower (Rewind Start) Used on Type No(s). 0015, 0025, 0109, 0110, 0111, 0115, 0116, 0117, 0118, 0120, 0121, 0123, 0124, 0125, 0134, 0136, 0137, 2015, 2025, 2109, 2110, 2111. ----- Note ----- 794105 Housing- Blower (Electric Start) Used on Type No(s). 0062, 0220, 2112, 2114.	365	793458	Screw (Carburetor) (27.0mm)	615	690340	Retainer-Governor Shaft
			371	794574	Gear-Cam	616	793448	Crank-Governor
			383	19576S	Wrench-Spark Plug	621	692310	Switch-Stop
			404	690272	Washer (Governor Crank)	623	793628	Seal-O Ring (Carburetor Spacer)
			425	793460	Screw (Air Cleaner Cover) (36.2mm)	635	66538S	Boot-Spark Plug
						662	793478	Stud (Rewind Starter) (M5x32.9mm Long)
						662A	793479	Stud (Rewind Starter) (M5x49.6mm Long)



100800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
670	793485	Spacer-Fuel Tank	851	493880S	Terminal-Spark Plug	969	690700	Screw
676	396548	Deflector-Muffler	857	793533	Tim-Blower Housing			(Blower Housing
677	690661	Screw			Cover			Cover)
		(Deflector) (SAE)	868	793507	Seal-Valve	972	793472	Tank-Fuel
		----- Note -----	875A	793192	Base Air Cleaner	975	793464	Bowl-Float
	699203	Screw	883	793497	Gasket-Exhaust	976	694395	Primer-Carburetor
		(Deflector) (Metric)	910	794101	Stud	1009	794099	Screw
718	690959	Pin-Locating			(Alternator)			(Starter Motor)
		(Cylinder)	914	794451	Screw			(M6x26mm Long)
741	793446	Gear-Timing			(Rocker Cover)	1022	793437	Gasket-Rocker Cover
742	795094	Retainer-E Ring			(15.8mm)	1023	793436	Cover-Rocker
745	793491	Screw	921	793531	Cover-Blower Housing	1036		Label-Emissions
		(Brake)	922	692135	Spring-Brake			(Available from
		(M5x25.3mm Long)	923	796635	Brake			A Briggs & Stratton
783	795099	Gear-Pinion			----- Note -----			Authorized Dealer)
783A	795096	Gear-Pinion			793490 Brake	1058	277099	Operator's Manual
787	793513	Arm-Lever			(No Longer Available)	1059	793471	Kit-Screw/Washer
793	793511	Screw/Nut Set			Used on Type No(s).			(Fuel Tank)
		(Lever Arm)			0015, 0025.	1095	793624	Gasket Set-Valve
832	793499	Guard-Muffler	925	793678	Cover-Linkage	1119	794100	Screw
		Used on Type No(s).	937	798330	Spline-Starter			(Alternator)
		0015, 0025, 0111,	942	793673	Bracket-Brake			(M5x29.8mm Long)
		0115, 0116, 0117,	955	793465	Plug-Carburetor	1208	699776	Screw
		0118, 0120, 0125,	957	692046	Cap-Fuel Tank			(Brake Bracket)
		0136, 0137, 2015,			(Black)	1263	697124	Reed-Breather
		2025, 2111, 2114.	957A	793606	Cap-Fuel Tank	1264	793453	Screw
832A	793681	Guard-Muffler			(Fresh Start)			(Breather Reed)
		Used on Type No(s).	958	698183	Valve-Fuel Shut Off			(M4x12.4mm Long)
		0062, 0109, 0110,			(Plastic)	1319	794467	Label-Warning
		0123, 0126, 0134,						
		0220, 2109, 2110,						
		2112.						
			968	793428	Cover-Air Cleaner	1375	793442	Cover-Breather/Reed
					Used on Type No(s).	1376	699851	Screw
					0015, 0025, 0062,			(Breather/Reed Cover)
836	793500	Screw			0109, 0110, 0137,			(M5x9.5mm Long)
		(Muffler Guard)			2015, 2025, 2109,	1395	793459	Screw
		(M5x12.3mm Long)			2110, 2112, 2114.			(Air Cleaner Base
842	691031	Seal-O Ring	968A	793432	Cover-Air Cleaner			to Carburetor)
		(Dipstick)			Used on Type No(s).			(34 15/16" Long)
843	691884	Sleeve-Lever			0123, 0126.			
847	793474	Dipstick/Tube	968B	793532	Cover-Air Cleaner			
		Assembly			Used on Type No(s).			
					0111, 0115, 0116,			
					0117, 0118, 0120,			
					0121, 0124, 0125,			
					0134, 0136, 0220,			
					2111.			

