




Section: TURBO 55S-55SE JARDIPRO JP 55 DAKOTA 55SH CHASSIS


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

9204

9288 9289 9604

9404 9488 9489 9689

1	1	1	1	1	1111-9091-01	Blade	
2	1	1	1	1	9987-5251-12	Screw	
3	1	1	1	1	9696-0011-01	Washer	
4	1	1	1	1	1111-9070-01	Blade holder	
5	1	1	1	1	9600-0014-00	Key	
8	1	1	1		1111-3020-01	Chassis-yellow	
8				1	1111-3020-08	Chassis-green	9689-65
8				1	1111-3020-02	Chassis-red	9604, 9689-75
9	1	1	1		1111-2793-01	Flap attachm.-yello	
9				1	1111-2793-02	Flap attachm.-black	
10	6	6	6	6	9947-0616-16	Screw	
11	1	1	1	1	1111-2792-01	Spring	
12				1	1111-3283-02	Flap-black	
12	1	1	1		1111-3283-01	Flap-yellow	
15	1	1	1	1	1111-2795-01	Rear attachment	
16	1	1	1	1	1111-3236-01	Attachment-LH	
17	1	1	1	1	1111-3237-01	Attachment-RH	
18	4	4	4	4	9836-9520-12	Screw	
19	1	1	1	1	9838-9522-12	Screw	
22	3	3	3	3	9955-3732-12	Screw	
25	1	1	1		1111-2840-01	Top collector-yello	
25				1	1111-2840-02	Top collector-black	
26	1	1	1	1	1111-2764-01	Cover	
27	1	1	1	1	1111-3032-01	Collecting bag	
28	1	1	1	1	1111-2843-01	Wire clamp	
29	2	2	2	2	9699-0100-02	Washer	
30	2	2	2	2	9838-9522-12	Screw	
99	1	1	1		1111-2893-12	Decal kit	STIGA



Section: TURBO 55S-55SE JARDIPRO JP 55 DAKOTA 55SH HANDLEBAR

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		9289				
		9489	9204			
	9288 9488	9689	9604			
1	1	1	1	1	1111-2805-02	Front axle
2	2	2	2	2	1111-1504-01	Retainer
3	2	2	2	2	9947-0616-16	Screw
4	1	1	1	1	1111-3031-01	Height adj.rod
5	2	2	2	2	9675-0011-00	Starlock
6	1	1	1	1	1111-2819-01	Spring
10	2	2	2	2	1111-1138-01	Spring
11	2	2	2	2	1111-2784-01	Wheel assy
12	1	1	1	1	1111-9047-01	.Ball bearing kit
13	2	2	2	2	1111-1184-01	..Bearing cone
14	2	2	2	2	1111-2785-01	Wheel cover
15	2	2	2	2	9699-0100-02	Washer
16	2	2	2	2	9943-0612-16	Screw
17	2	2	2	2	1111-3084-01	Hub cap-yellow
20	2	2	2	2	1111-3021-01	Handlebar attachmen
21	4	4	4	4	9795-3531-02	Nut
22	1	1	1	1	1111-3022-01	Handle-lower
23	4	4	4	4	1111-3023-01	Locking knob
24	2	2	2	2	9899-3557-12	Screw
25	2	2	2	2	9899-3545-12	Screw
26	6	6	6	6	9699-0028-02	Flat washer
27	2	2	2	2	9939-0820-16	Screw
28	2	2	2	2	1111-3024-01	Attachment plate
33	2	2	2	2	1111-0178-00	Reinforcement
43	1	1	1	1	1111-2957-01	Handle-upper
44	1	1	1	1	1111-3062-01	Eyelink
45			1		1111-2611-03	Throttle control
45A				1	1111-3301-03	Throttle control
46			1		9948-0645-16	Screw
47	1	1	1		9948-0640-16	Screw
47			1		9948-0660-16	Screw
47				1	9948-0670-16	Screw
48	1	1	1	1	9747-0631-02	Lock nut
52	1	1	1	1	1111-2953-01	Control handle
53				1	1111-2968-07	Engine brake cable
53	1	1	1		1111-2968-02	Engine brake cable
54	1	1	1	1	1111-2969-01	Cable attachment
56	2	2	3	2	1111-2018-01	Cable holder
57	2	2	3	2	9836-9216-12	Screw
61			1	1	9838-9512-12	Screw
62			1	1	9400-0218-00	Battery
63	1	1	1	1	1111-2927-01	Battery holder
64			1	1	9400-0219-00	Charger
65			2		9838-9540-12	Screw
66			1		1111-2020-01	Housing
67			1		1111-2021-01	Cover
68			1		9838-9216-12	Screw
69			1		1111-2825-01	Harness
70			1		9400-0186-00	Starting switch ass
71			1		1134-2848-01	.Ignition key
74			2		9838-9522-12	Screw
75			1		1111-2705-01	Cover
78			1		1111-2707-01	Housing
79			1	1	9401-0200-00	Cable holder

L = 57 mm

L = 45 mm

9689-65

9689-65

L = 40 mm

9689-65

L = 70 mm


9689-65, 2 st.

9289-25, 9689-65

9289-25, 9689-65

9289-25, 9689-65

9289-25, 9689-65



Section: TURBO 55S-55SE JARDIPRO JP 55 DAKOTA 55SH TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	9204					
	-25	9204	9489 9289			
	9288	-15	9689 9689			
	9604	9488	-75 -65			
1	1	1	1	1	1111-2808-01	Rear axle
2	2	2	2	2	1111-2814-01	Bushing
3	4	6	6	4	9947-0616-16	Screw
4	5	7	7	5	9838-9522-12	Screw
5	1	1	1	1	1111-2798-01	Height adj.quadrant
6	1	1	1	1	1111-2816-01	Height adj.lever
7	1	1	1	1	1111-2817-01	Lever knob
8	2	2	2	2	9943-0612-16	Screw
10	2	2	2	2	1111-3026-01	Wheel w.ball bearin
11	1	1	1	1	1111-9047-01	.Ball bearing kit
12	2	2	2	2	1111-1184-01	..Bearing cone
13	1	1	1	1	9549-0001-00	.Ball bearing
15	2	2	2	2	9699-0100-02	Washer
16	2	2	2	2	9943-0612-16	Screw
17	2	2	2	2	1111-3086-01	Hub cap-yellow
20	2	2	2	2	1111-3060-01	Spring
22	2	2	2	2	1111-2561-01	Cover plate
23	1	1	1	1	1111-2915-01	Engine belt pulley
24	1	1	1	1	9910-0612-16	Set screw
26	1	1	1	1	1111-3046-01	Transmission
27	1	1	1	1	1111-3047-01	Belt pulley
28	1	1	1	1	9595-0235-00	Locating pin
30	1	1	1	1	1111-2822-01	Tension spring
31	2	2	2	2	1111-2382-01	Pin
32	2	2	2	2	1111-3256-01	Drive key
33	2	2	2	2	9404-0083-00	Seal ring
36	4	4	4	4	9695-0013-00	Washer
37	2	2	2	2	1111-2829-01	Lock washer
38	2	2	2	2	1111-3075-01	Pinion-plastic whee
39	2	2	2	2	1111-2830-01	Support washer
41	2	2	2	2	9652-0010-04	Snap ring
45	1	1	1	1	1111-2967-01	Clutch cable
46	1	1	1	1	1111-2969-01	Cable attachment
47	1	1	1	1	1111-2954-01	Control handle
49	1	1	1	1	9948-0670-16	Screw
49	1	1	1	1	9948-0660-16	Screw
49	1	1	1	1	9948-0640-16	Screw
49	1	1	1	1	9948-0645-16	Screw
50	1	1	2	2	9747-0631-02	Lock nut
53	1	1	1	1	1111-3019-08	Cover-green
53	1	1	1	1	1111-3019-04	Cover-red
53	1	1	1	1	1111-3019-01	Cover-yellow
54	2	2	2	2	9838-9540-12	Screw
55	1	1	1	1	1111-2971-03	Variator control
56	1	1	1	1	9579-0008-00	Cable holder
57	1	1	1	1	1111-2941-01	.Knob
58	1	1	1	1	1111-3050-01	Bracket
61	1	1	1	1	9594-0026-00	Locating pin
62	1	1	1	1	1111-2469-01	Attachment
63	1	1	1	1	9943-0650-16	Screw
64	1	1	1	1	1111-2423-01	Spacer
65	1	1	1	1	1111-2433-01	Engine belt pulley
66	1	1	1	1	1111-9064-01	V-belt
67	1	1	1	1	1111-3051-01	Tension arm
68	1	1	1	1	9997-0630-12	Screw
69	1	1	1	1	1111-2747-01	Tension roller
70	1	1	1	1	1111-2746-01	Belt pulley
71	1	1	1	1	1111-3001-01	Variator assy
73	2	2	2	2	9699-0060-02	Flat washer

L = 70 mm

9689-65

L = 40 mm

9689-65

9689-65

9604-75, 9689-75